MÖLLER-CHEMIE STEINPFLEGEMITTEL GmbH
ZIEGELTALSTRASSE 2
D-93346 IHRLERSTEIN
TELEFON 09441-176940
TELEFAX 09441-1769499
www.moellerstonecare.eu
info@moellerstonecare.eu

MŒLLER STONE CARE

Care Instruction for NATURAL and ARTIFICIAL STONE FLOORING with Anti Slip R9 — *TI-30*

– cleaning, protection and maintenance –

Care instruction tested to DIN 51130

CONDITIONS

When treating a newly laid surface ensure sufficient drying time for the moisture to escape from the surface and substructure (maximum 2-4% residual moisture content).

Allow 2-3 weeks drying time for an adhesive bed and 4-6 weeks for mortar bed.

Drying times are indicative only and are subject to variation depending on the weather and the object and can be longer.

It's essential that any under-floor heating has been switched off and the surface is at a normal temperature, adequately cleaned, free of stains, dry and absorbent.

Always test in an inconspicuous place to determine suitability and coverage. Always read the labels carefully. Ensure the area around the surface to be treated is well ventilated.

CLEANING

Construction dirt:	**R55**	**Intensive Cleaner** -acid free-	Coverage: approx. 10-30 m²/litre
Cement smears:	**R69**	**Stone Cleaner** -special- please test if surface is acid resistance	Coverage: approx. 10-60 m²/litre
Stains:	Refer to Technical Information Sheet No. 1		

After cleaning the surface must be allowed to dry for at least 1 to 2 days to a residual moisture content of 2-4% before any further treatment can take place.

PROTECTION – inside and outside

Without enhancing colour:	**S32W**	**Stain Protection** -water based-	Coverage: approx. 5-20 m²/litre
Minimal colour enhancing:	**S34N**	**Stain Protection** -extra-	Coverage: approx. 5-20 m²/litre
Strong colour enhancing:	**S44**	**Colour Enhancer** -extra-	Coverage: approx. 5-20 m²/litre

Once dry the residual material is not harmful to health.

MAINTENANCE – inside and outside

Regular maintenance:	**P24**	**Liquid Stone Soap** -no rinse- (natural product) add approx. 25-50 ml for every 10 liters of wash water
Periodical intensive cleaning:	**R55**	**Intensive Cleaner** -acid free- for keeping anti slip R9 means 20 times P24, than do a cleaning with soft brush and R55

ENVIRONMENT

All specialist products comply with the German Detergent Act and are registered with the Federal Environmental Offices in Berlin.

Our specialized products have been recommended for decades by leading natural stone producers.

This technical instruction card is for advice only and is supplied without obligation. We require that the person making the application adapts all data concerning the application of the products to local conditions and the materials to be cleaned. We reserve the right to make changes to our products without warning as a result of technological advancement. The person conducting the application is responsible for any third person liabilities and ensuring compliance with any local laws or regulations.

Your local dealer:

All products are available from many reputable natural stone and tile dealers.

© MŒLLER STONE CARE GB-11.10

HMK-Reinigung-HMK-Schutz-HMK-Pflege-HMK-Reinigung-HMK-Schutz-HMK-Pflege-HMK-Reinigung-HMK-Schutz-HMK-Pflege-HMK-Reinigung-HMK-Schutz-HMK-Pflege-HMK